



DIGITECH

User Manual

Countdown Timer With Touchscreen LCD

QM-6325



Distributed by:
TechBrands by Electus Distribution Pty. Ltd.
320 Victoria Rd, Rydalmere
NSW 2116 Australia
Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500
www.techbrands.com

Specifications:

Backlight:	White LED
Countdown Range:	99 minutes and 59 seconds
Power:	2 x AAA batteries (required)
Dimensions:	80(H) x 80(W) x 25(D) mm

Instructions:

- Pull out the battery compartment and insert 2 x AAA batteries in the correct polarity.

Count down mode:

- Press the 'M' button continuously until you reach your desired minute.
- Press the 'S' button continuously until you reach your desired second.
- After the time has been set, press the 'S/S' button once to start the count down. Press the 'S/S' button again if you need to stop the count down at any time and 'S/S' again to start the count down.
- When the count down time reaches 00:00, the alarm will activate and sound for 30 seconds. To stop the alarm, press any key.
- After the alarm has stopped, the timer will return to the preset count down time.

Count up mode:

- Press 'M' and 'S' buttons simultaneously to reset the time to 00:00.
- Press the 'S/S' button to start count up minutes and seconds. Press the 'S/S' button to stop or start at any time.
- When the time reaches 99 minutes 59 seconds, the timer will automatically stop.
- The backlight will be on while the timer is being set, and will turn off automatically 35 seconds after the last touch.
- The backlight will turn on again when the alarm sounds or when any of the buttons are touched.

NOTE:

- When the LCD display becomes dimmer, please replace the batteries.
- Only use AAA batteries in this timer.
- Ensure not to mix old and new batteries.
- Please dispose of used batteries in a responsible manner.
- Never attempt to open, modify or repair the timer in any way.
- Never get the timer wet.