


AA2081
Bluetooth stereo headset
User' guides



■ Before using
Overview



- 1) Left Speaker
- 2) Right Speaker
- 3) Adjustable band
- 4) last song
- 5) volume down
- 6) Charging port
- 7) next song
- 8) LED Indicator
- 9) Power/Play/Pause/Hands free control Button (MFB)
- 10) Volume up
- 11) Built-in microphone

Charging the headset

* The headset comes with a built-in rechargeable battery, prior to first time use, it is recommended to charge the battery for at least 4 hours.

* When the headset is low power, the headset emits “beep” five tones every 5 minutes and the red LED flashes instead of the blue LED. Please recharge the headset when this occurs.

1. Connect the DC plug (cylinder style) in to the Charging port of the headphone (ref overview, point 8)
2. Plug opposite side in to a USB port of PC or USB power adaptor.
Red light on: Charging
Red light off: Charge complete
3. Average charge time is 1.5 hours

Switching on / off headset

Function	Operation	LED indicator	Indication tone
Switch on	Press the MFB button for 3-5 seconds, and release it till the blue LED is on	Blue LED is on for 1 second	“BI”
Switch off	Press the MFB button for 3-5 seconds, and release it till the red LED is on	Red LED is on for 1 second	“BI”

Note: In order to save power, the headset will turn off automatically if no Bluetooth device can be connected after 5 minutes.

How to enter pairing mode

Function	Operation	LED indicator	Indication tone
Enter pairing mode	Make sure the headset is off. Press and hold MFB button for 7-9 seconds, then release it till the red and blue LEDs blink alternately	Red and blue LEDs blink alternately.	Two “DU” tones

Note: Pairing mode will last 2 minutes. If no devices can be connected after 2 minutes, it will return to standby mode automatically.

Pairing the headset with Bluetooth mobile phone

Prior to using the headset for the first time, you have to pair it with a Bluetooth-enabled mobile phone. The pairing procedures are subject to different models of mobile phones. Please refer to your mobile phone user's manual for further information if required. The general pairing procedures are as follows:

- 1) Keep the headset and mobile phone within a 1 metre range when pairing.
- 2) Make the headset enter into pairing mode (Please refer to “how to enter into pairing mode”).
- 3) Activate your cell phone's Bluetooth function and set your cell phone to search for Bluetooth devices within range, and select “AA2081” from the list of devices shown;
- 4) According to indication, enter password or PIN No:”0000”, and press the key of” Yes” or “confirmed”.
- 5) After successful pairing, select “AA2081”in the Bluetooth device list and press “connect”.
- 6) After successful connecting, the blue LED of the headset quickly blinks twice or three times every 4 seconds.

Notes:

- ◆ If the pairing is not successful, please switch off headset firstly, and then re-pair according to the step 1~6 mentioned above.
- ◆ After pairing is successful, paired devices will remember each other. Unless pairing information is deleted because of new pairing, no need to pair when use next time. The headset can remember 8 paired devices, when paired devices exceed 8 paired devices, the first one will be replaced.
- ◆ If you want to pair the headset with other devices, please pair it with the new device according to steps 1~6 mentioned above.

Pairing headset with Bluetooth transmitter

You can connect the headset to a Bluetooth transmitter (i.e. smartphones, Bluetooth equipped speakers, etc) to enjoy music wirelessly. The pairing steps are as follows:

- 1) Keep your headset and transmitter within 1 metre when pairing.
- 2) Enter pairing mode on the headset (Please refer to “How to enter pairing mode).
- 3) Turn on the Bluetooth transmitter and enter pairing mode. It will search for Bluetooth devices automatically and send a pairing request.
- 4) When the headset requests PIN No, the Bluetooth transmitter need to respond “0000” automatically.
- 5) After successful pairing and connecting, the blue LED of headset quickly blinks twice every 4 seconds.

Notes:

- 1) The pairing password of AA2081 is “0000”, so, the headset can't pair with the Bluetooth transmitter which pairing password is not “0000”.
- 2) If the pairing is still not successful after trying several times, please refer to your Bluetooth transmitter manual carefully.

Pairing headset with Multi-devices

The headset can connect with two Bluetooth devices at most. If you want to finish the Multi-pairing, please refer to the following steps:

- 1) Firstly, pair the headset with Bluetooth transmitter (refer to “pairing headset with Bluetooth transmitter).
- 2) Switch off the Bluetooth transmitter.
- 3) Pair and connect the headset with the Bluetooth mobile phone (refer to “pairing headset with Bluetooth mobile phone”).
- 4) Restart Bluetooth transmitter, it will connect with headset automatically.

Making calls with the headset

Function	Status of headset	Operation
Voice dial	Standby mode	Press and hold < (last song) button for 2s, release it till hearing indication sound
Redial last number	Standby mode	Press MFB twice quickly
Volume up	Conversation mode	Press or hold + key
Volume down	Conversation mode	Press or hold - key
Answer calling	Ringling	Press MFB
Reject calling	Ringling	Press and hold MFB for 2s, and release it till hearing indication sound

Function	Status of headset	Operation
End calling	Conversation mode	Press MFB
Call transfer	Conversation mode	Press and hold MFB for 2s, and release it till hearing indication tone
Microphone mute	Conversation mode	Quickly press the MFB twice
Cancel mute	Conversation mode (mute)	Quickly press the MFB twice

Note:

- ◆ Not all the mobile phones support all the functions listed above. Please refer to your mobile phone user's manual.
- ◆ Different function and prompt tone according to different mobile phone.
- ◆ When the volume is adjusted to max or min, you will hear a prompt tone.
- ◆ When pressing the answer button on some mobile phones, the call will be transferred to the mobile phone. You can switch the call to the headset by using the conversation switch button or through operating on the mobile

phone. Please refer to your mobile phone user manual for further information.

Playing music

When the headset connects with the mobile phone or Bluetooth transmitter which supports A2DP, you can enjoy music through headset wirelessly.

Function	Status of the headset	Operation
Volume up	Playing music	Short or hold + key
Volume down	Playing music	Short or hold - key

Function	Status of headset	Operation
Pause	Playing music	Press MFB
Play	Pausing	Press MFB
Last song	Playing music	Press < key
Next song	Playing music	Press > key
Fast forward	Playing music	Hold > key
Rewind	Playing music	Hold > key

Notes:

- ◆ For some of mobile phones, when they are playing music, the music will transmit to the speaker of mobile phone, you have to choose “transmit the sound through Bluetooth” in the “setting” of music play interface, and then choose “AA2081” in the device list, the music will be transmitted to the headset. Please refer to the instruction of your mobile phone for further information.
- ◆ When the volume of headset is adjusted to max or min, you will hear an indication tone.
- ◆ Remote control the function of last song/next song/pause/revert, it needs your mobile phone or Bluetooth transmitter supports AVRCP. Please refer to the instruction of your mobile phone or Bluetooth transmitter for further information.

Restoring to factory defaults and resetting

Make sure the headset is off, press and hold MFB and + buttons simultaneously for about 8 seconds, release them when you hear two “DU” tones and see red LED is on, now the headset restores to factory defaults, and the pairing information will be deleted.

Charge the headset to make it reset.

LED Indicator Guide:

Charging

LED indicator	Status of the headset
Red LED is on	Charging
Red LED is off	Finish charging

Pairing with the Bluetooth devices

LED Indicator	Status of the headset
Red and blue LEDs blink alternately	Pairing mode
Blue LED quickly blinks once every 2 seconds.	Not connected to a device
Blue LED quickly blinks twice every 5 seconds	Set up HFP or A2DP connection
Blue LED quickly blinks three times every 5 seconds	Set up HFP and A2DP connection
Blue LED quickly blinks continuously	Conversation mode
Red LED blinks twice every 20 seconds	Low power

Indication tone

Indication tone	Status of headset
One tone every 3 seconds	Conversation mode and microphone mute
Three “DU” tones every 20 seconds	Low power

■ Care and maintenance

- ◆ Keep it dry and do not place in damp areas
- ◆ Keep the product away from direct sunlight or hot places
- ◆ Do not expose the product to extremely cold areas
- ◆ Do not attempt to disassemble the product
- ◆ Do not drop unit on hard surfaces
- ◆ Do not use chemical products or detergent to clean the product

■ Specifications

Bluetooth version	Bluetooth V3.0+EDR
Bluetooth profiles	Headset, Hands free, A2DP, AVRCP
Effective range	10 metres
Working time	Music: Up to 9 hours Talk: Up to 9 hours
Standby time	Up to 400 hours
Input	DC: 5V/500mA
Charging time	About 1.5 hours
Dimensions	162×153.5×32 mm
Weight	Approx. 99 g